



Item Description	Stock No.	Wt.
<b>(-) Cool-Air Tube with belt .....</b>	<b>04410</b>	<b>2</b>
1. Belt .....	04430	<.5
2. Quick disconnect .....	08449	<.5
3. Elbow, 1/4" male .....	08869	<.5
4. Seal kit (4 o-rings)* .....	08870	<.5
5. Cool-end venturi kit* .....	08871	<.5
6. Valve stem .....	08962	<.5
7. Valve insert .....	08963	<.5
8. Vortex tube assembly .....	23030	<.5
9. Spacer, narrow .....	08966	<.5
10. Tube, venturi .....	08967	<.5

Item Description	Stock No.	Wt.
11. Spacer, wide .....	08968	<.5
12. Helmet tube connection .....	08971	<.5
13. Screen .....	08973	<.5
14. Heat shield .....	08981	<.5
15. Knob with set screws .....	08985	<.5
16. Body .....	08961	<.5
17. Machine screw, round head 10-24 x 1/4" .....	08980	<.5
18. Belt clip .....	08974	<.5

\* Both items include the cool-end venturi o-ring.

### APPLICATION ALERT

The Cool Air Tube must be supplied with 20 cfm of grade D breathing air at 90 to 100 psig. It should always be used with an air filter which removes dust, dirt particles and oil mists from the air. (Do not exceed pressures noted in the Operations Manual.)